

Ecoustic® Meta Trimming Guidelines

All Ecoustic® Panel + Screen products must be installed with the correct top-to-bottom orientation to avoid any variation in colour and pattern direction.


The print does not extend to the edges of the panel or screen therefore an unprinted border occurs on all four sides and needs to be trimmed before installation even if using edging profile.

The position of the print **may not** be placed centrally within the physical panel therefore do not trim by measuring a fixed margin in from the panel edge. Instead follow the guidelines below to trim to the printed design.

- Ecoustic® Panel Meta: '+' crop marks are printed on each corner of the design to denote the edge of the pattern repeat. Align a straight edge to the '+' crop marks on all sides and trim to the print edge.
- Ecoustic® Screen Meta: '+' crop marks are printed on the LH corners of the design to denote the edge of the pattern repeat. Align a straight edge to the '+' crop marks on the LH side and trim a straight line from the '+' crop marks to the edge of the print for all other sides.
- **Do not** use other registration symbols printed on the panels as cutting guides.

Due to the artisan nature of the hand printing process, there may be slight variations in the prints so always check panels side by side for correct pattern matching prior to cutting and installing. Joins may be obvious upon installation and there will be a panelling effect.

Panel (1210 x 2720 mm / 8'11" x 3'11") Screen (2420 x 1210 mm / 3'11" x 7'11")



Screen Size: 2420 x 1210mm
Trim Size: 2400 x 1200mm
Pattern Repeat: 2400 x 1200mm

Panel Size: 1210 x 2720mm
Trim Size: 1200 x 2700mm
Pattern Repeat: 1200 x 2700mm

----- Trimming line

Ecoustic® Meta Trimming Guidelines: Panels Printed With Crop Marks

All Ecoustic® Panel + Screen products must be installed with the correct top-to-bottom orientation to avoid any variation in colour and pattern direction.

The print does not extend to the edges of the panel or screen therefore an unprinted border occurs on all four sides and needs to be trimmed before installation even if using edging profile.



The position of the print **may not** be placed centrally within the physical panel therefore do not trim by measuring a fixed margin in from the panel edge. Instead follow the guidelines below to trim to the printed design.

- Ecoustic® Panel Meta: '+' crop marks are printed on each corner of the design to denote the edge of the pattern. Align a straight edge to the '+' crop marks on all sides and trim to the edge of the print.
- Ecoustic® Screen Meta: '+' crop marks are printed on the LH corners of the design to denote the edge of the pattern. Align a straight edge to the '+' crop marks on the LH side and trim a straight line from the '+' crop marks to the edge of the print for all other sides.
- **Do not** use the other registration symbols printed on the panels as cutting guides. ↙

Due to the artisan nature of the hand printing process, there may be slight variations in the prints so always check panels side by side for correct pattern matching prior to cutting and installing. Joins may be obvious upon installation and there will be a panelling effect.

Panel (1210 x 2720 mm / 8'11" x 3'11")

Screen (2420 x 1210 mm / 3'11" x 7'11")



Screen Size: 2420 x 1210mm
Trim Size: 2400 x 1200mm
Pattern Repeat: 2400 x 1200mm

Panel Size: 1210 x 2720mm
Trim Size: 1200 x 2700mm
Pattern Repeat: 1200 x 2700mm

----- Trimming line